



Instructions for Mounting Safari Seat

This is a general set of instructions for mounting the Corbeau Safari seat to your CJ or YJ Jeep®. Please note that you may not need to use all the parts provided by Corbeau.

1. Remove the stock fold and tumble seat from your Jeep. ®
2. Remove the stock floor mounting brackets from the floor, be sure to keep the bolts.
3. Install the Corbeau mounting tabs to the floor using the existing bolts, don't tighten bolts all the way.
4. Mount Corbeau Safari seat to the mounting brackets and install cotter pins through the small hole in the floor mounting bracket.
5. Lock seat into position.
6. Tighten the front bolts in the floor mounting bracket.
7. Fold the seat forward and tighten the back bolts in the floor mounting bracket.

For CJ and YJ Jeeps that will require drilling (Usually the 85 and Older Vehicles)

1. Attach the (2) floor mounting brackets to the bottom of the seat by sliding the pins of the floor mounting bracket into the holes on the tabs that are located at the bottom front portion of the seat. Make sure the loops on the floor mounting bracket face the front of the vehicle.
2. Install cotter pins through the small hole in the floor mounting bracket pin of the left and right floor mounting brackets.
3. If your vehicle has carpet, cut the carpet so the floor mounting brackets are installed flush on the metal floor.
4. Set the seat in the rear of the vehicle with the seat back in the open/raised position. Maneuver the seat to the desired position in the vehicle.
5. Using the floor mounting brackets as templates, mark hole locations of the floor mounting brackets and remove the seat.
6. Center punch and drill a 25/64" hole at each mark, then remove the floor mounting brackets.
7. Align the floor mounting brackets over the drilled holes with the loops positioned toward the front of the vehicle.
8. From underneath the vehicle, align the tapping plates over the drilled holes and hold them in place.
9. Insert (2) 1.25x35mm bolts with (2) flat washers through each floor mounting bracket, loosely tighten the bolts.
10. Place the seat onto the rear vehicle floor and raise the seat into the upright seating position. Locate the lock pin on the seat hinge.
11. Orient the left and right side lock down brackets with the opening towards the top and rear of the vehicle. Place a lock down bracket over the lock pin. The bracket should be at a 10 degree angel to the floor with the bottom of the bracket tilted toward the rear.
12. Using the lock down bracket as a template, mark the locations of the holes in the bracket. Center punch the locations and drill a 21/64" hole at each mark.
13. While one person installs a lock down bracket inside the vehicle, using (2) 1.25x33mm bolts, a second person places a tapping over the holes from under the wheel well, loosely tighten the bolts.
14. Repeat this procedure for both sides of the vehicle.
15. Adjust the seat height to make sure the seat locks into the side lock down brackets and tighten all bolts.

DISCLAIMER

No warranty or representation is made as to this product's ability to protect the user from injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this product are directly related to the manner in which it is installed used and/or maintained.

Jeep® is a registered trademark of The Daimler Chrysler Corporation