



Instructions for Mounting Direct Bolt-In Seats in CJ/YJ Jeeps®

1. Remove the stock seat and bracket from the existing floor pan.
2. Separate the stock seat from the stock bracket by removing the bolts that attach the seat to your stock sliders.
3. Mount your Corbeau seat to the stock bracket and slider using the 4 bolts provided. Locate the correct mounting pattern by placing the bracket on the seat and positioning the bracket so the four holes in the track align with the four mounting holes. The bracket should be positioned in the center of the seat.
4. Re-Install your stock bracket and Corbeau seat to the floor pan. Use the stock bolts and bolt holes to secure the bracket to the floor pan.
5. Be sure that all bolts are secured tightly before operating your vehicle.

Jeep® is a registered trademark of The Daimler Chrysler Corporation

If you have any further questions about installing your seats and brackets, feel free to contact Corbeau
info@corbeau.com
801-255-3737