



Protecting Your Adventure Lifestyle

Warrior, Inc.  
16850 SW Upper Boones Ferry Rd  
Ste. A  
Durham, OR 97224  
Phone: (888) 220-6861  
Fax: (503) 692-0364  
[customerservice@warriorproducts.com](mailto:customerservice@warriorproducts.com)  
[www.warriorproducts.com](http://www.warriorproducts.com)

=====

**SUBJECT:** Part #2245 – JK High Clearance Off-Road Tailpipe Kit

**IMPORTANT:** While this kit includes clamps for installation, we highly recommend that you have the exhaust system tack welded into place after installation. Clamps are not terribly reliable and have a tendency to loosen themselves.

**TOOLS:** Simple hand tools are required to complete this installation.

1. Remove your factory muffler. It is clamp bolted to your exhaust piping just above the rear axle, and is hung from rubber hangers. Do not damage the rubber hangers during removal. Also remove the heat shield bolted to the vehicle above the muffler if you desire. If you are installing this kit along with our #2205 JK Locking Security Trunk, that heat shield will need to be removed. (Note: It is much easier to install the trunk first, so if you've purchased both, it is best to do it with the exhaust removed)

#### **TAILPIPE INSTALL**

2. Slide your tailpipe onto the factory piping just above the rear axle, and attach the hanger hook on the tailpipe to the rubber factory hanger.
3. You should have a small amount of adjustment ability to move the tailpipe into place as you'd like.
4. Once happy with the tailpipe's location, install and tighten your exhaust clamp.



#### **FINAL INSTALL**

5. While exhaust clamps were provided to install this product, we have found issues with loosening clamps. We have found that when using clamps along with the stainless factory pipe and the stainless muffler, the clamps cannot squeeze the piping well, and they have a tendency to work themselves loose over time. Warrior Products recommends that once installed, tack welds should be placed at each joint to hold the assembly together more reliably.

This completes the installation of your new Warrior Products JK High Clearance Off-Road Tailpipe Kit. If you want to see what else Warrior has to offer, please visit us online at [www.warriorproducts.com](http://www.warriorproducts.com). If you need further assistance installing your product, please contact us by email at [customerservice@warriorproducts.com](mailto:customerservice@warriorproducts.com) or call us at (888) 220-6861.

**THANK YOU FOR PURCHASING WARRIOR PRODUCTS**

**QUALITY**



**INTEGRITY**



**INNOVATION**



**SERVICE**