



Protecting Your Adventure Lifestyle

Warrior Products, Inc.
16850 SW Upper Boones Ferry Rd
Ste. A
Durham, OR 97224
Phone (888) 220-6861
Fax (503) 692-0364
sales@warriorproducts.com

07-15 JK 4DR SIDE CAGE NET 40600

Note: This side cage netting kit covers the open sides of the rear cargo area. For overhead coverage of the rear seats and cargo area, Warrior also offers the 40500 Center Cage Net kit. A 40800 Basic Cargo Cover which spans the top of the tub is also available.

Tools needed

Cordless Drill
7/64" Drill Bit
Phillips Screwdriver

Supplied Parts

(2) Side Cage Net
(4) Footman Loop
(8) #10 x 1/2" Oval Head Sheet Metal Screw

Installation:

1. There are (4) footman loops that need to be installed onto the Jeep. The first pair are to be installed onto the Jeep. The first pair are to be mounted to the forward edge of the tub rail, one on either side. **(Fig. 1)** Hold the footman loop against the tub rail and make a mark through the attachment points. Utilize a center punch then drill out the marks with a 7/64th drill bit. Use the provided sheet metal screws to affix the footman loops to the tub rail. The second pair are mounted to either the plastic roll bar surround bases ('11-'13 JKs) or the roll bars themselves ('07-'10 JKs). **(Fig. 2)**
2. Locate the driver side Corner Cage Net and position it so the WP logo is facing outward. Loosely attach the forward most upper and lower loop attachments then proceed with the rear most footman loop attachment.
3. The 45 degree corner strap wraps around the outside of the roll bar and buckles together underneath the rear cross bar. Wrap the remaining strap around the diagonal bar and snug up all the straps evenly. Repeat steps 2 & 3 for the passenger side.



If you need further assistance installing your product, please contact us by email at techsupport@warriorproducts.com or call us at (888) 220-6861.

**THANK YOU FOR PURCHASING
WARRIOR PRODUCTS**

QUALITY

INTEGRITY

INNOVATION

SERVICE