



Warrior, Inc.
11100 SW Industrial Way
Tualatin, Oregon 97062
(503) 691-8915 Main
(503) 692-0364 Fax
(888) 220-6861 Toll Free
techsupport@warriorproducts.com

SUBJECT: P/N 865/867 – Tow Bar D-Ring Adapters

NOTE: This kit was designed and based to fit the Warrior #860 Collapsing Tow Bar. It should however work with any Tow Bar constructed from rectangular or square tubing with a 2" vertical height and ½" vertical holes in the ends where the brackets mount.

Installation:

1. Remove the ½" bolts holding the swivel brackets on the end of your 860 tow bar. Set your swivel brackets aside as they will not be used with the D-Ring Adapters.
2. Bolt your new Tow Bar D-Ring Adapters into place where the swivel brackets were bolted.
3. Installation and removal of your tow bar is now as simple as lining up the adapters to the d-ring mounts on your bumper and sliding the supplied clevis pins into place. Be sure to push the supplied cotter pins into place as well.
4. Your installation of the adapters is now complete.

For more Warrior towing and exterior accessories, please visit our online catalog at www.warriorproducts.com

If you need further assistance installing your product, please contact us by email at techsupport@warriorproducts.com or call us at (888) 220-6861.