

2360 Boswell Road
Chula Vista, CA 91914
Phone 619.216.1444
Fax 619.216.1474
E-Mail tech@explorerprocomp.com

**Latest Revision:
8.16.2021**



PRO COMP SUSPENSION

58000

K1007/ 08/ 09/ 10/ 11/ 12/ 13/ 19/ 20/ 21/ 22/ 58/ 59/ 60

K1007T/ 08T/ 09T/ 10T/ 11T/ 12T/ 13T/ 19/ 20T/ 21T

22T /58T/ 59T /60T

K1121/ 22/ 23/ 24/ 25

K1121T/ 22T/ 23T/ 24T/ 25T

1973-76 Chevrolet U- Bolt Kit

This document contains very important information that includes warranty information and instructions for resolving problems you may encounter. Please keep it in the vehicle as a permanent record.

Part #	Description	Qty.	Illus.	Page
	Box 1 of 5-PN 11411 (K1008/11/20/59/K1122/ K1125)			
11411	GM 4.0IN LIFT FRONT SPRING	2	-	-
	(Or) Box 1 of 5-PN 11511 (K1007/10/13/22/23)			
11511	73-87 K10/20 6IN F SPRING	2	-	-
	(Or) Box 1 of 5-PN 11211 (K1009/12/21/60 K1121/ K1124)			
11211	73-87 GM 2.5	2	-	-
	Box 2 of 5-PN 58101 (K1007/8/9/22/1124/25)			
58101	73-76 GM F U-BOLT KIT	1	-	-
	(OR) Box 2 of 5-PN 58201 (K1010/11/12/13/59/60)			
58201	76.5-87 GM F U-BOLT KIT	1	-	-
	(OR) Box 2 of 5-PN 58301 (K1020/21/K1121/22/23)			
58301	88-91 GM SUV F U-BOLT KIT	1	-	-
	(OR) Box 2 of 5-PN 13122 (K1007/10/13/22/23)			
13122	ADD A LEAF	1	-	-
	Box 3 of 5-PN 58401 (K1007/08//10/11/13/20)			
58401	GM BLOCK KIT	1	-	-
	(OR) Box 3 of 5-PN 58402 (K1022/59/K1122/23/25)			
58402	4IN GM BLOCK AND U-BOLT KIT	1	-	-
	(OR) Box 3 of 5-PN 58251 (K1009/12/21)			
58251	73-91 K10 2.5IN BLOCK KIT	1	-	-

Part #	Description	Qty.	Illus.	Page
	Box PN 58252 (K1060/ K1121/24)			
58252	73-91 K10/K20 4IN LIFT KIT	1	-	-
	Box 7215 for (K1007/10/22/K1123)			
7215	73-91 GM S/S BRK LINES	1	-	-
	Box 7220 for (K1013)			
7220	79-86 GM S/S BRK LINES	1	-	-
	Box 4 of 5-PN GM400 (K1007/08/10/11/13/20/22/59/ K1122/23/25)			
GM400	73-91 K10/20 4IN LIFT	2	-	-
	Box 5 of 5-PN 322500/326500 (K1008)			
322500	FRONT SHOCKS	2	-	-
326500	REAR SHOCKS	2	-	-
	(OR) Box 5 of 5-PN 924509B/929500B (K1007T/ 10T/13T/19T/22T/ K1123T)			
924509B	FRONT SHOCKS	2	-	-
929500B	REAR SHOCKS	2	-	-
	(OR) Box 5 of 5-PN 922500B/926500B (K1008T/11T/20T/59T/K1122T/ K1125T)			
922500B	FRONT SHOCKS	2	-	-
926500B	REAR SHOCKS	2	-	-
	(OR) Box 5 of 5-PN 921500B/925509B (K1009T/21T/60T /K1121T/24T)			
921500B	FRONT SHOCKS	2	-	-
925509B	REAR SHOCKS	2	-	-
	(OR) Box 5 of 5-PN 922500B/926500B (K1012T)			
922500B	FRONT SHOCKS	2	-	-
925509B	REAR SHOCKS	2	-	-

Introduction:

- ◆ **This installation requires a professional mechanic!**
- ◆ We recommend that you have access to a factory service manual to assist in the disassembly and reassembly of your vehicle. It contains a wealth of detailed information.
- ◆ Prior to installation, carefully inspect the vehicle's steering and driveline systems paying close attention to the tie rod ends, ball joints, wheel bearing preload, pitman and idler arms. Additionally, check steering-to-frame and suspension-to-frame attaching points for stress cracks. The overall vehicle must be in excellent working condition. Repair or replace all worn or damaged parts!
- ◆ Read the instructions carefully and study the illustrations before attempting installation! You may save yourself a lot of extra work.
- ◆ Check the parts and hardware against the parts list to assure that your kit is complete. Separating parts according to the areas where they will be used and placing the hardware with the brackets before you begin will save installation time.
- ◆ Check the special equipment list and ensure the availability of these tools.
- ◆ Secure and properly block vehicle prior to beginning installation.
- ◆ ***ALWAYS*** wear safety glasses when using power tools or working under the vehicle!
- ◆ Use caution when cutting is required under the vehicle. The factory undercoating is flammable. Take appropriate precautions. **Have a fire extinguisher close at hand.**
- ◆ Foot pound torque readings are listed on the Torque Specifications chart at the end of the instructions. These are to be used unless specifically directed otherwise. Apply thread lock retaining compound where specified.
- ◆ *Please note that while every effort is made to ensure that the installation of your Pro Comp lift kit is a positive experience, variations in construction and assembly in the vehicle manufacturing process will virtually ensure that some parts may seem difficult to install. Additionally, the current trend in manufacturing of vehicles results in a frame that is highly flexible and may shift slightly on disassembly prior to installation. The use of pry bars and tapered punches for alignment is considered normal and usually does not indicate a faulty product. However, if you are uncertain about some aspect of the installation process, please feel free to call our tech support department at the number listed on the cover page. We do not recommend that you modify the Pro Comp parts in any way as this will void any warranty expressed or implied by the Pro Comp Suspension company.*

Please Note:

- ⇒ Front suspension and head light realignment is necessary!
- ⇒ Speedometer and ABS recalibration will be necessary if larger tires (10% more than stock diameter) are installed.
- ⇒ **IT IS ADVISABLE THAT YOU HAVE HELP AVAILABLE WHEN INSTALLING THIS KIT. SOME COMPONENTS ARE HEAVY AND AWKWARD. AN ADDITIONAL SET OF HANDS IS GOOD INSURANCE AGAINST INJURY!**

⇒ ***Please read all instructions from start to finish before you begin the installation.***

FRONT SPRING REMOVAL

- 1) Raise the front of vehicle and support the frame in front of axle.
- 2) Remove front shock absorbers.
- 3) Remove U-bolts, nuts, washers, and spring plates.
- 4) Remove spring pivot bolts and nuts.
- 5) Remove front springs.

FRONT SPRINGS INSTALLATION

- 1) If necessary, enlarge spring plate holes from 7/16" to 1/2" to accommodate larger U-bolts.
- 2) Mount springs in vehicle and install pivot bolts and nuts. Hand tighten only at this time.
- 3) Install new U-bolts, washers and nylock nuts. Torque U-bolts to 55-65 ft./lbs.
- 4) Install shocks.
- 5) Remove supports and lower vehicle.
- 6) Torque pivot bolts to 25-35 ft./lbs.

NOTE: DO NOT USE ANY DEGREE SHIMS ON FRONT AXLE.

REAR SPRINGS REMOVAL

- 1) Raise the rear of vehicle and support frame ahead of axle.
- 2) Remove rear shock absorbers.
- 3) Remove U-bolts, nuts, washers and spring plates.
- 4) Remove spring pivot bolts and nuts.
- 5) Remove rear springs.

REAR SPRINGS INSTALLATION

- 1) If necessary, enlarge spring plate holes from 7/16" to 1/2" to accommodate larger U-bolts.
- 2) Mount springs in vehicle and install pivot bolts and nuts. Hand tighten only at this time.

NOTE: On kits 50020 and 50030, it will be necessary to install the caster degree shims between the spring pad and the new rear spring. On kit 50020, your spring width will determine which two shims you should use.

- 3) Install new U-bolts, washers and nylock nuts. Torque U-bolts to 55-65 ft./lbs.
- 4) Install shocks.
- 5) Remove supports and lower vehicle.
- 6) Torque pivot bolts to 25-35 ft./lbs.

NOTE: Raise your vehicle so the suspension hangs free. A bumper Jack or jack stands will be required for this operation; do this on both the front and rear. Rotate the drive shaft by hand and check for any possible universal joint to yoke binding. At this time inspect brake lines for any binds, kinks, etc. Brake lines must not be tight with suspension fully extended.

Revision Page:

6.16.05: Latest Revision

8.16.21: Added Kit K1007T-13T/ 19T-22T/ 58T/60T and K1121T- K1125T

Use this only as a guide for hardware without a called out torque specification in the instruction manual.

Bolt Torque and ID						
Decimal System			Metric System			
All Torques in Ft. Lbs. Maximums						
Bolt Size	Grade 5	Grade 8	Bolt Size	Class 9.8	Class 10.9	Class 12.9
5/16	15	20	M6	5	9	12
3/8	30	45	M8	18	23	27
7/16	45	60	M10	32	45	50
1/2	65	90	M12	55	75	90
9/16	95	130	M14	85	120	145
5/8	135	175	M16	130	165	210
3/4	185	280	M18	170	240	290

1/2-13x1.75 HHCS D T L X Grade 5 Grade 8 (No. of Marks + 2)	M12-1.25x50 HHCS D T L X
G = Grade (Bolt Strength) D = Nominal Diameter (Inches) T = Thread Count (Threads per Inch) L = Length (Inches) X = Description (Hex Head Cap Screw)	P = Property Class (Bolt Strength) D = Nominal Diameter (Millimeters) T = Thread Pitch (Thread Width, mm) L = Length (Millimeters) X = Description (Hex Head Cap Screw)

Notice to Owner operator, Dealer and Installer:

Vehicles that have been enhanced for off-road performance often have unique handling characteristics due to the higher center of gravity and larger tires. This vehicle may handle, react and stop differently than many passenger cars or unmodified vehicles, both on and off-road. You must drive your vehicle safely! Extreme care should always be taken to prevent vehicle rollover or loss of control, which can result in serious injury or even death. Always avoid sudden sharp turns or abrupt maneuvers and allow more time and distance for braking! Pro Comp reminds you to fasten your seat belts at all times and reduce speed! We will gladly answer any questions concerning the design, function, maintenance and correct use of our products.

Please make sure your Dealer/Installer explains and delivers all warning notices, warranty forms and instruction sheets included with Pro Comp product.

Application listings in this catalog have been carefully fit checked for each model and year denoted. However, Pro Comp reserves the right to update as necessary, without notice, and will not be held responsible for misprints, changes or variations made by vehicle manufacturers. Please call when in question regarding new model year, vehicles not listed by specific body or chassis styles or vehicles not originally distributed in the USA.

Please note that certain mechanical aspects of any suspension lift product may accelerate ordinary wear of original equipment components. Further, installation of certain Pro Comp products may void the vehicle's factory warranty as it pertains to certain covered parts; it is the consumer's responsibility to check with their local dealer for warranty coverage before installation of the lift.

Warranty and Return policy:

Pro Comp warrants its full line of products to be free from defects in workmanship and materials. Pro Comp's obligation under this warranty is limited to repair or replacement, at Pro Comp's option, of the defective product. Any and all costs of removal, installation, freight or incidental or consequential damages are expressly excluded from this warranty. Pro Comp is not responsible for damages and / or warranty of other vehicle parts related or non-related to the installation of Pro Comp product. A consumer who makes the decision to modify his vehicle with aftermarket components of any kind will assume all risk and responsibility for potential damages incurred as a result of their chosen modifications. Warranty coverage does not include consumer opinions regarding ride comfort, fitment and design. Warranty claims can be made directly with Pro Comp or at any factory authorized Pro Comp dealer.

IMPORTANT! To validate the warranty on this purchase please be sure to mail in the warranty card.

Claims not covered under warranty-

- Parts subject to normal wear, this includes bushings, bump stops, ball joints, tie rod ends and heim joints
 - Discontinued products at Pro Comp's discretion
- Bent or dented product
- Finish after 90 days
- Leaf or coil springs used without proper bump stops
- Light bulbs
- Products with evident damage caused by abrasion or contact with other items
- Damage caused as a result of not following recommendations or requirements called out in the installation manuals
- Products used in applications other than listed in Pro Comp's catalog
- Components or accessories used in conjunction with other manufacturer's systems
- Tire & Wheel Warranty as per Pro Competition Tire Company policy
- Warranty claims without "Proof of Purchase"
- Pro Comp Pro Runner coil over shocks are considered a serviceable shock with a one-year warranty against leakage only. Rebuild service and replacement parts will be available and sold separately by Pro Comp. Contact Pro Comp for specific service charges.
- Pro Comp accepts no responsibility for any altered product, improper installation, lack of or improper maintenance, or improper use of our products.

E-Mail: tech@explorerprocomp.com
Website: www.explorerprocomp.com
Fax: (619) 216-1474
Ph: (619) 216-1444

<p>PLACE WARRANTY REGISTRATION NUMBER HERE: _____</p>
